

# Panneaux de retour Quik Trak

## Renseignements sur le projet

Nom du poste :	Lieu :
Ingénieur :	Date de soumission:
Entrepreneur :	Présentée par:
Représentant du fabricant :	Approuvé par :

## Données techniques

Material	Wood
Subcomponent Material	1/2" plywood with aluminum backing
Prop 65 label required?	Yes

## Informations sur le produit et utilisation de l'application

Quik Trak® Return Panels feature a U-shaped groove to complete tubing turns. Each return panel includes a separate aluminum sheet for installation beneath the panel. Use with 5/16" Wirsbo hePEX™ tubing only.



Nom de la pièce	Numéro de pièce	A [inch]	B [inch]	C [inch]	Weight per UOM [lbs/UOM]
Quik Trak 7" x 48" Return Panels	A5060702	47.66	6.72	0.5	2.8

## L'installation

Place Quik Trak Panels on floor surface, ensuring the seams are staggered. Secure one side of the panel with a screw on each end to allow for quick realignment of panels. After properly placing the panels, secure each one with ten screws (five on each side of the groove). Clean any debris from the panel grooves. Apply a thin, 1/8" bead of 100% silicone Quik Trak Sealant (E6050010) throughout the entire length of the groove. The silicone acts as an adhesive agent, promoting good heat transfer from the tubing to the panel. Install the tubing according to the design. For additional information, refer to the Uponor Quik Trak Installation Manual and the Uponor Radiant Floor Heating Installation Handbook.

## Applications connexes

Radiant Heating and Cooling Systems

## Notes de bas de page

## Coordonnées de la personne-ressource

Uponor Inc.  
5925 148th Street West  
Apple Valley, MN 55124  
T 800.321.4739  
F 952.891.2008

Uponor Ltd.  
6510 Kennedy Road  
Mississauga, ON L5T 2X4  
T 888.594.7726  
F 800.638.9517