Wirsbo Genius

Quick Installation manual

1. Connect the actuators to the control unit. Loosen the blue contacts.



5. Connect the Programmer and Control Unit with the white cable supplied.




2. Fasten the actuator cables into the blue contacts.






3. Using pliers, break-off the plastic where the cable will pass through the box



6. Replace the Control Unit lid and connect to 240V fused supply.



4. Push the blue contact back into position. Squeeze the cable together and push it into the cable channel. Install all the actuators in the same way. A maximum of 12 can be installed into one box.



7. At the programmer, choose the language using the arrow keys and confirm by pressing "OK".





8. Press the "CLOCK" and set the correct time and day using the left-right arrow keys. Confirm by pressing "OK".



11. Push the other end of the black cable into the thermostat.



9. The thermostats are installed using the black cable supplied. Push the cable into the socket at the side of the Control Unit.



12. Select the channel to which the thermostat is to be assigned with the horizontal arrow keys and confirm with "OK". If the thermostat controls several channels repeat the programming by disconnecting the cable and connecting it again.



10. Note room designation and channel number(s) on the thermostat label.

To connect the installation cable to the thermostat, first open the battery lid on the back of the thermostat.



13. To erase the channel assigned to the thermostat, press "SHIFT" and then the "UP-ARROW". Confirm by pressing the "OK" button for 3 seconds.



