

© Copyright Uponor Limited

Copyright in this drawing belongs to Uponor Limited.
This drawing may not be used, sold, licensed,
transferred, copied or reproduced in whole or in part or
in any manner or form other than with the prior written
consent of Uponor Limited.

Uponor

Electrical Schematic

Smatrix Move

Ref: SM-1.0A

**Refer to the Quick
Start Guide to setup
pump and zone valve.**

Uponor reserve the right to alter specifications and
operating parameters for all their systems at any time as
part of their policy of continuous product development.

