### **Chapter 8:** *Radiant floor system design*

Although it is easiest to quickly and accurately create a radiant design with a software program, it's essential to understand how to design a system manually to help make decisions and alterations to optimize system performance.

To design a radiant floor system, one must determine the:

- BTU/h/ft<sup>2</sup> heat loss for each room
- Floor surface temperature
- Project installation method
- Piping type and size
- Finished floor material R-value
- Piping on-center distance
- Supply water temperature
- Loop length, including leader distance
- Fluid flow in gpm
- Pressure loss or head

### **Radiant floor design tutorial**

To demonstrate radiant floor design, this tutorial moves step by step through the design of a single room (Bedroom 1) in the Uponor Training House. The complete Training House radiant floor heat loss and design information is provided on **pages 72-85**.

**Figure 8-1** shows a partial floor plan for the Uponor Training House including Bedroom 1.

### **Laundry** 7'6" x 10' **Bath 1** 7'6" x 10' **Bedroom 1** 12' x 10' 8' x 2' 8' x 2' Manifold

**Figure 8-1: Uponor training house (partial)**

### **Step 1: Heat-loss analysis**

The radiant floor design worksheet provides a format to organize the building's raw heat-loss information. A copy of this worksheet is available in **Appendix A**. Copy as necessary. Fill out the worksheet for the project, and then enter the information into the computer heat-loss program. Entering the data into the computer will go much faster if you complete the worksheet first. Take special note of the input for floor covering R-values and the different floor insulation types and values.

**Figure 8-2** shows heat-loss data from the design program for Bedroom 1.

### **Note:** When

determining system performance data, note which load to use: upward, downward or total. All load-related entries require the upward load value. The total load value is only used when calculating flow information.



**Figure 8-2: Heat-loss data for bedroom 1**

### **Radiant floor design worksheet**

**Project name:** Training House main level

			Loop 1
	A	Room name	Bedroom 1
Step 1	B	Room setpoint temp. (°F)	$65^{\circ}$ F
	C	Zone number	1
	D	Upward load (BTU/h/ft <sup>2</sup> )	19.8
	E	Total load (BTU/h/ft <sup>2</sup> )	24.8
	F	Floor surface temp. (°F)	
	G	Installation method	
	н	Piping size	
	T	Floor covering R-value	
	J	Differential temp. (°F)	
	K	Piping o.c. distance (in)	
	L	Supply water temp. (°F)	
	M	Active loop length	
	N	Leader loop length	
	o	Total loop length	
	P	Loop flow in gpm	
	Q	Loop head pressure (ft)	
	R	Loop balancing turns	
<b>Manifold totals</b> ld			
	S	Supply water temp. (°F)	
	T	Manifold flow in gpm	
	U	Highest pressure head (ft)	

**Figure 8-3: Radiant floor design worksheet**

Use the radiant floor worksheet (**Appendix B**) when manually designing a system. Note that this appendix also contains worksheets for radiant ceiling and Quik Trak® designs. Make a copy of the worksheet prior to beginning this tutorial.

From the selected heat-loss information given for Bedroom 1, enter the following information into the appropriate cell on the worksheet:

- Room name
- Room setpoint temperature
- Upward BTU/h/ft<sup>2</sup> load
- Total BTU/h/ft<sup>2</sup> load (upward and downward added together)

**Note:** Obtain BTU/h/ft<sup>2</sup> values either from the design printout or calculate manually by dividing the BTU/h by the floor area (in square feet) where piping can be installed. Remember to subtract areas where piping will not be installed. All load values in this tutorial are BTU/h/ft<sup>2</sup>.

### **Step 2: Floor surface temperature**

The floor surface temperature is the temperature at the top of the floor needed to transfer the calculated BTU/h into the room at the maximum designed heat load. This surface temperature is based solely on the floor area. Floor covering, construction or piping on-center distances do not influence the required surface temperature. If conditions are milder than design,

the floor surface temperature will be lower. Surface temperature is based on a simple relationship between the room setpoint temperature and the required upward BTU/h/ft<sup>2</sup> load. Do not include downward BTU/h/ ft<sup>2</sup> loss when calculating floor surface temperature. Areas with differing BTU/h/ft<sup>2</sup> requirements or setpoint requirements have different surface temperatures.

The coefficient of radiant floor thermal transfer is 2.0 BTU/h/ft<sup>2</sup>/°F. This transfer coefficient changes as the position of the radiant panel changes in the room. Radiant wall has a transfer coefficient of 1.8, and radiant ceiling has a transfer coefficient of 1.6. Simply put, the floor surface temperature is equal to the room setpoint temperature plus half the required upward BTU/h/ft<sup>2</sup> load.

**For bedroom 1:** (19.8 BTU/h/ft<sup>2</sup> ÷ 2 BTU/h/ft2 ) + 65°F = 74.9°F floor surface temperature.

The formula used to calculate the floor surface temperature is precise and is supplied by the design program. If manually designing the system, use the formula or the floor surface temperature chart found in **Appendix C**. This chart is also shown in **Figure 8-4**. This chart quickly brackets the floor surface temperature to determine if the temperature is within requirements.

**Floor surface temperature limitations** — Hardwood floors have a maximum floor surface temperature of 80°F. Please consult the wood flooring manufacturer for their recommendations. All other flooring types have a maximum floor surface temperature of 87.5°F.

Using the floor surface temperature chart:

**Find:** The required floor surface temperature.

### **Procedure:**

- 1. Find the desired room setpoint temperature in the first column of the table; for this example, use 65°F.
- 2. Move right until you reach the correct upward BTU/h/ft<sup>2</sup> requirement (19.8). The chart is divided into five BTU/h/ft2 increments. If between values, round to the next higher value. For this example of 19.8 BTU/h/ft<sup>2</sup>, use the 20 BTU/h/ft<sup>2</sup> entry.
- 3. The temperature found at the intersection of the two values is the bracketed floor surface temperature.

Keep in mind this chart is used to quickly assess whether the floor surface temperature is within limitations. At 75°F floor surface temperature, the room floor surface temperature is well within all limitations. Actual floor surface temperature is 74.9°F.

If the design does not use wood flooring, and the required surface temperature exceeds 87.5°F, reduce the heat loss of the room or add



### **Radiant floor surface temperatures**

Exceeds the maximum recommended surface temperature for all floors.

Exceeds the maximum recommended surface temperature for hardwood floors.

### **Figure 8-4: Excerpt from radiant floor surface temperatures chart**

supplemental heat. Take the same action for wood flooring applications when the floor surface temperature exceeds 80°F.

Reversing the floor surface temperature formula determines the maximum load in BTU/h/ft<sup>2</sup> for a room. To calculate the maximum upward BTU/h/ft<sup>2</sup> at a given room setpoint temperature, use this equation:

 $(87.5^{\circ}F -$  room setpoint) x 2 = maximum BTU/h/ft<sup>2</sup>

Using this formula, a room with a setpoint temperature of 65°F will support 45 BTU/h/ft<sup>2</sup> for a maximum upward BTU/h/ft<sup>2</sup> load. Conversely, if the room setpoint temperature is 70°F, then 35 BTU/h/ft2 is the maximum upward load. Obviously, if wood flooring is used, the BTU/h/ft<sup>2</sup> capability is less. Remember, these loads are maximum capabilities and may be reduced by floor construction and floor covering selections.

Enter 74.9°F in the floor surface temperature cell on the worksheet.

### **Step 3: Installation method**

Next, determine which installation method to use for the particular job. Of all the options outlined in **Chapter 6**, the most common are:

- Slab on or below grade
- Poured-floor underlayment
- Quik Trak
- Joist Trak
- Joist heating

Sometimes the decision is obvious, but other times the designer may help influence the decision. For instance, does the actual heat source have a fixed water temperature that must be designed around? Has the building already been framed, making pouredfloor underlayment impractical? What is the project budget? Consider all these factors when determining an installation method.

**One final note:** there really is no best or preferred installation method. All have their applications, advantages and limitations. In addition, the superior efficiency of radiant floor heating in general makes any installation method preferable over other heat-delivery options.

For this tutorial, use the poured-floor underlayment for the type of installation method. In the floor construction cell on the worksheet, enter "Poured Floor."

### **Step 4: Piping size**

People often ask, "Do you get more heat out of  $\frac{1}{2}$ " piping than  $\frac{3}{8}$ " piping?" The surprising answer is no, not really. The most common piping sizes used in radiant floor heating are  $\frac{3}{8}$ " and  $\frac{1}{2}$ ". Both are fairly equal in terms of heat output per square foot when installed in a radiant mass. Remember, the floor — not the piping — is the heat emitter. The piping merely carries water to the heat emitter.

Larger piping sizes do allow for longer loop lengths due to lower friction losses at the same flow rates, but do not increase the actual per square foot heat output of a radiant system to any extent. Other factors, such as installation method, piping spacing, water temperature, finished floor materials and flow are more important factors in determining performance capabilities.

The biggest difference between piping sizes is pressure loss. Smaller piping produces much greater pressure loss than larger piping. Therefore, shorter loop lengths are suggested for smaller-diameter piping. This pressure loss, rather than heat output, is the determining factor when it comes to selecting a piping size.

Enter ½" Wirsbo hePEX in the piping size cell on the worksheet.

### **Radiant floor design worksheet**

### **Project name:** Training House main level



**Figure 8-5: Radiant floor design worksheet U** Highest pressure head (ft)

### **Step 5: Finished floor covering R-value**

The next step is to determine the type of finished flooring material and its corresponding R-value. This information is needed to determine the appropriate supply water temperature. **Appendix D** includes a chart listing a variety of common floor coverings and their R-values; an excerpt of the chart is shown in **Figure 8-7**.

Use the chart to select the floor covering closest to the proposed floor covering.

Many times the finished floor material is unknown at the time of design. People will question, "Shouldn't I simply design for the worst possible case?" This approach may prevent a potential under-design problem. However, it frequently leads to over-design issues, where more piping or excessive supply water temperatures may be needlessly factored into a job, adding to the overall design cost. Designers must carefully weigh the overall results of

### **Radiant floor design worksheet**

**Project name:** Training House main level



**U** Highest pressure head (ft)

**Figure 8-6: Radiant floor design worksheet**

66 l Uponor complete design assistance manual [uponor-usa.com | uponor.ca](https://www.uponorpro.com/)

their design decisions, especially with floor coverings.

**Find:** The R-value of 1/4-inch nylon saxony carpet with 1/<sub>4</sub>-inch bonded urethane padding (4-lb. density).

### **Procedure:**

- **1** In the R-value table, find the type of carpeting to be installed.
- **2** Move to the right and read the value for the appropriate thickness.
- **3** In this example, the R-value of 1/4-inch nylon saxony is 0.88.
- **4** In the R-value table, find the type of carpet pad to be installed.
- **5** Move to the right and read the value for the appropriate thickness.
- **6** In this example, the R-value of ¼-inch bonded urethane is 1.04.
- 7. Add the two values together to obtain the total R-value: 0.88 + 1.04 = 1.92
- 8. Enter 1.92 in the floor covering R-value cell on the worksheet.

**1**

**4**

### **Step 6: Determining differential temperature**

The supply and return differential temperature is the temperature drop from the supply manifold to the return manifold. A supply and return differential temperature of 10°F is ideal for residential radiant floors. A 20°F differential temperature is common for commercial projects. For the exercise, use a supply and return differential temperature of 10°F.

Enter 10°F in the differential temperature cell on the worksheet.

### **Step 7: On-center distance**

Piping on-center distance is a function of flow, temperature and comfort. You must deliver the required flow through the piping at the selected piping on-center distance and be within the operational temperature range of the floor construction medium (e.g., concrete, underlayment, etc.).

Decreasing the piping spacing (bringing the piping closer together) will lower the required supply water temperature and produce a more even surface temperature, but increases the amount of piping used in the project.

For poured-floor underlayments, the maximum on-center distance is





**Figure 8-7: Excerpt from floor covering R-value chart**

9 inches. Due to the shallow depth of the pour, install the piping closer together to avoid possible striping, which creates warm and cool spots across the floor. If the supply water temperature is found to be too high later in the design process, reduce the on-center distances.

Enter 9 inches in the on-center distance cell on the worksheet.

### **Step 8: Supply water temperature**

The required supply water temperature is the temperature necessary to provide the amount of energy required to create the floor surface temperature as it relates to the upward resistance of floor coverings. Supply water temperature is based on a complex relationship between the conditions above and below the radiant mass and several other characteristics of the installation.

The factors required to calculate supply water temperature are:

- Installation method
- Required upward BTU/h/ft<sup>2</sup> load
- Room setpoint temperature
- Floor covering R-value
- Supply and return differential temperature

The required information to determine

the supply water temperature is known. Use the appropriate chart in **Appendix E** (see **Figure 8-8**).

**Find:** The required supply water temperature for a load of 19.8 BTU/h/ft<sup>2</sup> using poured-floor underlayment construction with piping at 9 inches on center with a floor covering R-value of 1.92.

### **Procedure:**

- **1** Find the appropriate supply water temperature chart (poured-floor underlayment with piping 9 inches on center).
- **2** Enter the chart in the BTU/h/ft<sup>2</sup> column for the given load (19.8 BTU/h/ft<sup>2</sup>).
- **3** Move to the right until intersecting the approximate R-value slope line. The slope line for this R-value (1.92) falls between the published lines in the chart.
- 4. Move straight down from the intersecting point of the 1.92 R-value line and the 19.8  $BTU/h/ft^2$  line.
- 5. Read the required supply water temperature at the appropriate differential temperature. The required water temperature for Bedroom 1 is 132°F.

Enter 132°F in the supply water temperature cell on the worksheet.

**Note:** If the calculated downward loss in BTU/h/ft<sup>2</sup> exceeds the upward load requirement, use the greater of the two values when calculating the supply water temperature.

Concrete slabs and poured-floor underlayments thicker than the depth shown on the charts in **Appendix E** require slightly higher supply water temperatures.

If the supply water temperature exceeds the piping's sustained operating temperature or the floor construction limitation, the best ways to decrease the water temperature are to:

- Reduce the piping on-center distance
- Reduce the floor covering R-value
- Reduce the upward heat loss through improved insulation
- Provide supplemental heat

The maximum operating water temperature for concrete is 150°F and 140°F for poured-floor underlayment (verify with the product manufacturer). When installing piping between floor joists, with or without heat emission plates, limit the supply water design temperature to 165°F.



**Note:** Uponor's recommended maximum fluid temperature for all concrete applications is 150°F, in accordance with the UBC. Consult underlayment manufacturer's recommended temperature limitations. This data assumes negligible downward loss in accordance with good insulation practices.

### **Figure 8-8: Excerpt from supply water temperature chart**

### **Step 9: Determine loop length**

Loop length is a function of room size, piping on-center distance and the length of the piping that runs to and from the manifold (leader distance).

**Active loop length** — To determine the amount of piping to be installed in a room, use the following multipliers:

- 12" o.c. Multiply the square footage of the room by 1.0
- 10" o.c. Multiply the square footage of the room by 1.2
- 9" o.c. Multiply the square footage of the room by 1.33
- 8" o.c. Multiply the square footage of the room by 1.5
- 7" o.c. Multiply the square footage of the room by 1.7
- 6" o.c. Multiply the square footage of the room by 2.0

### **Radiant floor design worksheet**

**Project name:** Training House main level



### **Manifold totals**

- **S** Supply water temp. (°F)
- **T** Manifold flow in gpm
- **U** Highest pressure head (ft)

**Figure 8-9: Radiant floor design worksheet**

These factors determine the amount of active piping to install in the room.

**Find:** The active loop length for Bedroom 1 with the piping installed at 9 inches on center.

### **Procedure:**

- 1. Multiply the square footage of the room by the appropriate multiplier: 132 ft<sup>2</sup> x 1.33 = 176 feet
- 2. The active loop length for Bedroom 1 is 176 feet.

Enter 176 feet in the active loop length cell on the worksheet.

**Leader length** — To determine the leader length for the loop, add the horizontal distance from the room to the manifold to include any vertical distance. Multiply this value by two (supply and return) to obtain the leader length for the loop. To determine the total loop length, add the active loop length to the leader length.

**Find:** The leader length for Bedroom 1.

### **Procedure:**

- 1. Add the horizontal distance from the room to the manifold location and back to the amount of vertical distance at the manifold location.
- 2. The manifold location is approximately 20 feet from Bedroom 1. Multiply this distance by 2 (to account for supply and return piping) to obtain the amount of horizontal piping in the leader length:  $20 \times 2 = 40$  feet
- 3. At the manifold location, this example will require approximately 5 feet of piping to run from the floor to the manifold and back to the floor (roughly 2 feet on one side with 3 feet on the other). Add the horizontal and vertical piping amounts together:  $40 + 5 = 45$  feet
- 4. The total leader length for Bedroom 1 is 45 feet.

Enter 45 feet in the leader length cell on the worksheet.

**Find:** The total loop length for Bedroom 1.

### **Procedure:**

- 1. Add the active loop length to the leader length to obtain the total loop length: 176 + 45 = 221
- 2. The total loop length for Bedroom 1 is 221 feet.

Enter 221 feet in the total loop length cell on the worksheet.

### **Step 10: Calculating fluid flow**

To satisfy the calculated heat load, the system must provide adequate fluid flow through each loop of the hydronic radiant floor system. Fluid flow is based on a relationship between the heat load, active loop length and the supply and return differential temperature. The information required to calculate fluid flow includes:

- Required total BTU/h/ft<sup>2</sup> load (upward and downward combined)
- Piping on-center distance
- Active loop length

For Bedroom 1 of the Training House, the total load from the heat loss is 24.8 BTU/h/ft<sup>2</sup>. The active loop length, based on 9 inches on-center spacing, is 176 feet.

Use the charts in **Appendix F** to calculate flow for each loop in the system. Select the appropriate chart for the water or water-and-glycol mixture when calculating flow.

**Find:** The required flow per loop.

### **Procedure:**

- 1. Find the appropriate chart based on the type of fluid used. In this tutorial, use the 100% water chart (see **Figure 8-10**).
- **2** Enter the chart at the total BTU/h/ft<sup>2</sup> load (24.8) in the BTU/h/ft<sup>2</sup> column. In small applications, round to the nearest BTU/h/ft<sup>2</sup> value (25 BTU/h/ft<sup>2</sup>) or use the formula in **Step 3** to determine the flow per foot value for the actual BTU/h/ft<sup>2</sup>.
- **3** For actual flow value, move to the right until you intersect the column for 9 inches on center for 25 BTU/h/ft<sup>2</sup>.
- **4** The flow value is 0.00380 gpm per foot of piping.
- 5. Using the actual flow, multiply it by the active loop length:  $0.00380 \times 176 = 0.67$  gpm

Enter 0.67 gpm in the flow per loop cell in the worksheet.

### **Step 11: Pressure loss**

To calculate the feet of pressure head drop (ft hd) for the loop, use the following information: flow per loop, total loop length, size of piping, type of piping, supply water temperature and fluid concentration.

The flow for this loop is 0.67 gallons per minute. The total loop length is 221 feet. The type and size of piping is ½" Wirsbo hePEX. The supply water temperature is 132°F. The fluid concentration is 100% water.

**Find:** Feet of head drop.

### **Procedure:**

- 1. Find the appropriate chart in **Appendix G** (100% water using ½" Wirsbo hePEX).
- 2. Enter the gpm column and round to the nearest flow for the loop (0.72 gpm).
- 3. Move right to the closest supply water column for the manifold (130ºF).

**Note:** If the system water temperature is between two columns, round up or down to the nearest temperature. If the temperature falls exactly between two columns (110°F for example), use the lower temperature column (100°F). For this example, use the 130°F column.

- 4. Read the feet of head drop per foot (0.02094).
- per foot by the total loop length to determine total feet of head for the 5. Multiply the feet of head value loop. (0.02094 x 221 = 4.6')

Normally, the feet of head calculations are completed only after the manifold supply water temperature is known (after the project design is completed). The feet of head loss is completed now for training purposes.

If the head loss is higher than desired after completing the pressure-loss calculation, you may need to decrease loop length(s), add loops or increase the PEX piping size.

If the piping size or total loop length change, recalculate pressure loss using the new loop length or piping size (and corresponding water temperature).

Enter 4.6 feet of head in the loop head pressure cell in the worksheet.

calculated for the Training House This completes the design of Bedroom 1. Once all rooms are designed and tutorial, perform the initial flow balancing and determine the system totals. The answers for the tutorial are on **page 88**.

### 100% Water | 10° Supply/return differential flow in GPM per foot of piping.



**Figure 8-10: Excerpt from 100% water flow chart on page 194**

### **System reminders**

### **Water temperature**

When designing a radiant system, a situation may arise where different loops serving different rooms on the same manifold have different required water temperatures. Typically, if this difference is no greater than 20°F to 25°F, it will not impact the system. This, of course, will vary depending on room traffic patterns and floor coverings.

However, if the difference is greater than 25°F, consider some design changes to reduce the temperature differential.

First, in wet applications (poured-floor underlayment), decrease the piping spacing of the loops requiring higher water temperatures. This will lower the required water temperature in those loops while maintaining the same output and floor surface temperature. However, loop length and pressure loss will increase, which may necessitate adding a second loop to that area.

Second, in dry installations (between the joists), you may choose to add aluminum heat emission plates to lower the water temperature.

Third, decreasing the finished floor R-value will lead to lower required water temperatures.

Last, move the higher supply water temperature loops to another manifold and run appropriate water temperature to that manifold.

### **Head and GPM**

When calculating the flow and head total for a system, gpm (or total flow) is cumulative. The flow of all loops served by a single circulator should be added together. Head (or pressure loss) is not cumulative. Simply select the highest pressure drop of all the loops per manifold served by that circulator. Remember to add in the supply and return mechanical piping and any other appliances the circulator will push flow through.

When selecting a circulator, consult the manufacturer's published performance curves, and select the circulator that best fits the specific gpm and head requirements for the project.

### **The complete design**

The following is the entire room schedule for the Uponor Training House. The floor plans and heat-loss information appear on **pages 72 to 85**. Finish the design with the worksheet started by Bedroom 1. See **page 88** for the completed tutorial design calculations.



**Figure 8-11: Room, window and door schedules**



**Figure 8-12: Main-level floor plan (no scale)**

![](_page_8_Figure_2.jpeg)

**Lower-level floor plan (no scale) Figure 8-13: Lower-level floor plan (no scale)**

![](_page_9_Picture_8.jpeg)

July 08, 2020 **Heat Loss Detail** 

Project #: A-Z Heating Supply Name:Training House

### **Basement**

![](_page_10_Picture_47.jpeg)

## Component Losses

 $\mathsf{30}\,{}^\circ\mathsf{F}$ 

![](_page_10_Picture_48.jpeg)

 $Rv = hr \cdot ft^{2.0}F/btu$ <br>N = Not Heated Temperature = °F Fowrate = USGPM Air Flow = cfm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr-ff<sup>9</sup>)<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt Length = ft Area = ft<sup>2</sup><br>Head Loss = ft water

# See end of report for important Notes and Disclaimers.

Page 2 of 14

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0094 R

Project #: A-Z Heating Supply Name:Training House

Bedroom 4

![](_page_11_Picture_67.jpeg)

![](_page_11_Picture_68.jpeg)

Supplemental Heating Type: Required Supply Temp:

0 Btu/hr 2,408 Btu/hr 3,117 Btu/hr

Supplemental Heat Supply:

Total Radiant Load: Net Upward Load:

Other<br>98 °F

Embedded Slab

## Component Losses

![](_page_11_Picture_69.jpeg)

Page 3 of 14

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0094 R

See end of report for important Notes and Disclaimers.

Length = ft Area = ft° Temperature = °F Flowrate = USGPM Air Flow = d'm Heat Loss = Bu/hr Unit Heat Loss = Btu/(hr.ft°) Rv = hr.ft°-'F/btu<br>Head Loss = ft water RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH

July 08, 2020 **Heat Loss Detail** 

Project #:A- Z Heating Supply Name:Training House

![](_page_12_Picture_33.jpeg)

## Component Losses

![](_page_12_Picture_34.jpeg)

Temperature = °F Flowrate = USGPM Air Flow = cfm Heat Loss = Btu/hr Unit Heat Loss = Btu/hr ff°) Rv = hr ff° °F/btu<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt N = Not Heate Length = ft Area = ft<sup>2</sup><br>Head Loss = ft water

Uponor complete design assistance manual 175

Project #: A-Z Heating Supply Name:Training House

Rec Room

![](_page_13_Picture_93.jpeg)

0 Btu/hr

Recovered Floor Loss: Gross Upward Load:

1.9 hr-ft<sup>2</sup>-°F/btu

Embedded Slab

 $229$  ft<sup>2</sup>

Net Heated Area:

Floor Cover Rv: Panel Type:

1,065 Btu/hr

0 Btu/hr 1,065 Btu/hr

Supplemental Heat Supply:

Total Radiant Load: Net Upward Load:

Other<br>80 °F

Supplemental Heating Type: Required Supply Temp:

1,688 Btu/hr

Component Losses

![](_page_13_Picture_94.jpeg)

Page 5 of 14

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0094 R

See end of report for important Notes and Disclaimers.

Length = ft Area = ft° Temperature = °F Flowrate = USGPM Air Flow = d'm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr.ft°) Rv = hr.ft°-°F/btu<br>Head Loss = ft water RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OT

July 08, 2020 **Heat Loss Detail** 

Project #: A-Z Heating Supply Name:Training House

![](_page_14_Picture_41.jpeg)

## Component Losses

![](_page_14_Picture_42.jpeg)

Temperature = °F Flowrate = USGPM Air Flow = cfm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr.ft°) Rv = hr.ft°-'Fl*b*u<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt N = Not Hea Length = ft Area = ft<sup>2</sup><br>Head Loss = ft water

Uponor complete design assistance manual 177

Project #: A-Z Heating Supply Name:Training House

![](_page_15_Picture_80.jpeg)

![](_page_15_Picture_81.jpeg)

0 Btu/hr

Supplemental Heat Supply:

Net Upward Load:<br>Total Radiant Load:

Recovered Floor Loss: Gross Upward Load:

Floor Back Loss: Net Room Load:

1,817 Btu/hr

2,146 Btu/hr

329 Btu/hr -315 Btu/hr

1,817 Btu/hr

## Component Losses

![](_page_15_Picture_82.jpeg)

## Length = ft Area = ft° Temperature = °F Flowrate = USGPM Air Flow = d'm Heat Loss = Bu/hr Unit Heat Loss = Btu/(hr.ft°) Rv = hr.ft°-'F/btu<br>Head Loss = ft water RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH See end of report for important Notes and Disclaimers.

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0094 R

Page 7 of 14

Project #: A-Z Heating Supply Name:Training House

![](_page_16_Picture_41.jpeg)

## Component Losses

![](_page_16_Picture_42.jpeg)

 $Rv = hr<sup>-ft<sup>2</sup> \cdot F/btu</sup>$ <br>N = Not Heated Temperature = °F Flowrate = USGPM Air Flow = ofm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr.ft<sup>x</sup>)<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt Length = ft Area = ft<sup>2</sup><br>Head Loss = ft water

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.00094 R

Project #: A-Z Heating Supply Name: Training House

Bedroom<sub>2</sub>

![](_page_17_Picture_101.jpeg)

0 Btu/hr

431 Btu/hr 932 Btu/hr 499 Btu/hr

405 Btu/hr 026 Btu/hr

![](_page_17_Picture_102.jpeg)

0 Btu/hr

Supplemental Heat Supply:

Total Radiant Load: Net Upward Load:

Recovered Floor Loss: Gross Upward Load:

Floor Back Loss: Net Room Load: Surface Temp:

2,464 Btu/hr

3,431 Btu/hr

2,464 Btu/hr

2,499 Btu/hr 967 Btu/hr -932 Btu/hr

 $73°F$ 

## Component Losses

![](_page_17_Picture_103.jpeg)

Page 9 of 14

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0094 R

See end of report for important Notes and Disclaimers.

Project #: A-Z Heating Supply Name:Training House

![](_page_18_Picture_44.jpeg)

## Component Losses

Net Upward Load:<br>Total Radiant Load:

Other<br>127 °F

![](_page_18_Picture_45.jpeg)

 $Rv = hr<sup>-ft<sup>2</sup> \cdot F/btu</sup>$ <br>N = Not Heated Temperature = °F Flowrate = USGPM Air Flow = ofm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr.ft<sup>x</sup>)<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt Length = ft Area = ft<sup>2</sup><br>Head Loss = ft water

Uponor complete design assistance manual 1 81

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.00094 R

Project #: A-Z Heating Supply Name:Training House

Dining / Kitchen

![](_page_19_Picture_108.jpeg)

0 Btu/hr

670 Btu/hr 2,544 Btu/hr -493 Btu/hr

2,720 Btu/hr

3,213 Btu/hr

## **Heating System**

![](_page_19_Picture_109.jpeg)

0 Btu/hr 2,687 Btu/hr

Supplemental Heat Supply:

Total Radiant Load: Net Upward Load:

Recovered Floor Loss: Gross Upward Load:

Floor Back Loss:

Net Room Load: Surface Temp:

3,213 Btu/hr

2,720 Btu/hr 526 Btu/hr -493 Btu/hr 2,687 Btu/hr

 $10.02$ 

## Component Losses

![](_page_19_Picture_110.jpeg)

![](_page_19_Picture_111.jpeg)

Created Using LoopCAD 2020 Uponor(US) (7/14/2020)<br>Version:20.0.0094 R

Length = ft Area = ft° Temperature = °F Flowrate = USGPM Air Flow = d'm Heat Loss = Bru/hr Unit Heat Loss = Btu/(hr.ft°) Rv = hr.ft°-°F/btu<br>Head Loss = ft water RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OT

See end of report for important Notes and Disclaimers.

Project #: A- Z Heating Supply Name:Training House

![](_page_20_Picture_53.jpeg)

![](_page_20_Picture_54.jpeg)

## Component Losses

Required Supply Temp:

3,376 Btu/hr<br>4,028 Btu/hr 0 Btu/hr

Supplemental Heat Supply:<br>Net Upward Load:<br>Total Radiant Load:

![](_page_20_Picture_55.jpeg)

 $Rv = hr \cdot ff^2 \cdot F/btu$ <br>N = Not Heated Temperature = °F Flowrate = USGPM Air Flow = dfm Heat Loss = Btu/hr Unit Heat Loss = Btu/(hr ft<sup>p</sup>)<br>RH = Radiant Floor Heating BB = Baseboard FA = Forced Air OTH = Other Heating SM = Snowmelt Length = ft Area =  $ft^2$ <br>Head Loss = ft water

![](_page_21_Picture_169.jpeg)

![](_page_21_Picture_170.jpeg)

![](_page_21_Picture_5.jpeg)

Exterior Wall Insulation: 10.0 hr ft<sup>2, o</sup>F*b*tu<br>Slab Insulation: 10.0 hr ft<sup>2, o</sup>F*btu*<br>s concrete walls

![](_page_21_Picture_171.jpeg)

**Described**<br> **Concerns with an original concerns of the definition moter hostings**<br>
Concerns with a concern with the state of the position of the concerns of the state of the state of the "Fibu<br>
Concerns with the state in

![](_page_22_Picture_67.jpeg)

[uponor-usa.com | uponor.ca](https://www.uponorpro.com/) Uponor complete design assistance manual l 85 1DPH7UDLQLQJ+RXVH 3URMHFW\$=+HDWLQJ6XSSO\ **+HDW/RVV'HWDLO** -XO\ **'LVFODLPHUV** :LWKWKHSHUPLVVLRQRI\$6+5\$(SRUWLRQVRIWKH\$6+5\$(+DQGERRN±)XQGDPHQWDOVDUHUHSURGXFHGLQWKLVVRIWZDUHLQFOXGLQJWKH&OLPDWLF'HVLJQ&RQGLWLRQVGDWD7KHSURJUDPDQGGDWDDUHSURYLGHGDVLVZLWKRXWZDUUDQW\ RIDQ\NLQGHLWKHUH[SUHVVHGRULPSOLHG7KHHQWLUHULVNDVWKHTXDOLW\DQGSHUIRUPDQFHRIWKHSURJUDPDQGGDWDLVZLWK\RX,QQRHYHQWZLOO\$6+5\$(EHOLDEOHWR\RXIRUDQ\GDPDJHVLQFOXGLQJZLWKRXWOLPLWDWLRQDQ\ORVWSURILWVORVW VDYLQJVRURWKHULQFLGHQWDORUFRQVHTXHQWLDOGDPDJHVDULVLQJRXWRIWKHXVHRULQDELOLW\WRXVHWKLVSURJUDPRUWKHGDWD\$6+5\$(\$PHULFDQ6RFLHW\RI+HDWLQJ5HIULJHUDWLQJDQG\$LU&RQGLWLRQLQJ(QJLQHHUV,QF &ROGZHDWKHUKXPLGLILFDWLRQRUVRPHOLIHVW\OHVWKDWSURGXFHH[FHVVLYHPRLVWXUHPD\FDXVHFRQGHQVDWLRQWRRFFXULIWKHDEVROXWHKXPLGLW\RIWKHLQGRRUDLULVWRRKLJKIRUWKHPRPHQWDU\FLUFXPVWDQFHV&RQGHQVDWLRQFDQRFFXURQ VXUIDFHVRUFRQFHDOHGZLWKLQWKHVWUXFWXUHDQGFDQOHDGWRPROGPLOGHZIURVWGDPDJHDQGPRLVWXUHGDPDJH7KHVRIWZDUHGRHVQRWSHUIRUPFDOFXODWLRQVIRUWKHHVWLPDWLRQRUGHWHFWLRQRISRVVLEOHFRQGHQVDWLRQSUREOHPVDQGLWLV WKHGHVLJQHUVLHVRIWZDUHXVHUVUHVSRQVLELOLW\WRGRVRLQGHSHQGHQWO\LIUHTXLUHG 7KHFDOFXODWHGYDOXHVVKRZQLQWKLVUHSRUWDUHEDVHGRQWKHGDWDLQSXWE\WKHXVHURIWKHVRIWZDUH,QDFFXUDWHRUHUURQHRXVGDWDLQSXWZLOOUHVXOWLQLQDFFXUDWHRUHUURQHRXVUHVXOWV<RXDUHVWURQJO\DGYLVHGWRUHYLHZDOOLQSXWGDWD FDUHIXOO\DQGWRKDYHWKHFDOFXODWHGUHVXOWVUHYLHZHGE\DQH[SHULHQFHGKHDWLQJSURIHVVLRQDOWRHQVXUHUHDVRQDEOHQHVVDQGVXLWDELOLW\IRU\RXUDSSOLFDWLRQ ,112(9(17:,//\$9(1,562)7:\$5(,1&³\$9(1,5´25,76\$)),/,\$7(6%(/,\$%/(81'(5\$1<&2175\$&71(\*/,\*(1&(675,&7/,\$%,/,7< 2527+(5/(\*\$/25(48,7\$%/(7+(25<)25\$1<&216(48(17,\$/,1&,'(17\$/,1',5(&725 63(&,\$/25381,7,9('\$0\$\*(6:+\$762(9(5,1&/8',1\*%87127/,0,7('72'\$0\$\*(6)25/2662)%86,1(66352),76%86,1(66,17(55837,21/2662)%86,1(66,1)250\$7,2125'\$7\$\$1'7+(/,.((9(1 ,)68&+3\$57< +\$6%((1\$'9,6('2)7+(3266,%,/,7<2)68&+'\$0\$\*(6\$9(1,5¶6&808/\$7,9(/,\$%,/,7<)520\$1<&\$86(5(/\$7('7225\$5,6,1\*)5207+(86(7+,65(3257\$1'5(\*\$5'/(662)7+()2502)7+(\$&7,216+\$//%(/,0,7('72 12\*5(\$7(57+\$17+(\$028172))((63\$,'72\$9(1,581'(57+(62)7:\$5(/,&(16(\$\*5((0(17 &UHDWHG8VLQJ/RRS&\$'8SRQRU86 9HUVLRQ5 /HQJWK IW \$UHD IWð7HPSHUDWXUH ))ORZUDWH 86\*30\$LU)ORZ FIP+HDW/RVV %WXKU8QLW+HDW/RVV %WXKUāIWð5Y KUāIWðā)EWX +HDG/RVV IWZDWHU5+ 5DGLDQW)ORRU+HDWLQJ%% %DVHERDUG)\$ )RUFHG\$LU27+ 2WKHU+HDWLQJ60 6QRZPHOW1 1RW+HDWHG **6HHHQGRIUHSRUWIRULPSRUWDQW1RWHVDQG'LVFODLPHUV** 3DJHRI

![](_page_23_Picture_470.jpeg)

![](_page_23_Picture_471.jpeg)

![](_page_23_Picture_472.jpeg)

- -
- 
- 
- -
- **G** Enter the installation method. **G** Enter the installation method.
- H Enter the size of PEX piping for project. **H** Enter the size of PEX piping for project.
- **I** Refer to **Appendix D** for floor covering information.
- **J** Indicate differential temperature (10°F for residential; 15°F for light commercial; 20°F for commercial).
- **K** Maximum piping o.c. distance is 12" for residential. Do not exceed 9" o.c. under tile or linoleum.
- **L** Use information from **Rows D, G, I, K** with **Appendix E** to obtain the supply water temperature.
- **M** Enter the length of piping installed within the room (i.e., active loop).
- **N** Enter the length of the piping from the room being heated to the respective manifold and multiply by 2 to account for both the supply and return.
- O Use formula:  $(Row M + Row N) = total loop length$ **O** Use formula: (**Row M** + **Row N**) = total loop length.

**x**

- **P** Use the values in **Rows E** and **M** with **Appendix F** to obtain the flow per loop.
- **Q** Use the values in **Rows H** and **P** with **Appendix G** to obtain the head pressure per loop. Choose the appropriate solution (water or water/glycol solution).
	- **R** Enter highest temperature from **Row L**.
- **S** Add and enter all values from **Row P**.
	- **T** Enter highest value from **Row Q**.

![](_page_24_Figure_0.jpeg)

**Figure 8-14: Lower-level floor plan (no scale)**

![](_page_25_Picture_565.jpeg)

## **Manifold totals**

![](_page_25_Picture_566.jpeg)

- **A** Enter the name of the room. The room may have more than one loop.
- **B** Room setpoint temperature is normally 65°F for radiant floor.
- **C** Zone is equal to thermostat.
- **D** Enter the "Floor Unit Load to Room" value from design program printout (upward load).
- **E** Enter the "Floor Unit Load" value from design program printout (total load).
- **F** (**Row D**/2) + **Row B** = floor surface temperature. Do not exceed 87.5°F for all floors (exception: wood floor limit is 80°F).
- **G** Enter the installation method. **G** Enter the installation method.

**H** Enter the size of PEX piping for project. **I** Refer to **Appendix D** for floor covering information.

- **J** Indicate differential temperature (10°F for residential; 15°F for light commercial; 20°F for commercial).
- **K** Maximum piping o.c. distance is 12" for residential. Do not exceed 9" o.c. under tile or linoleum.
- **L** Use information from **Rows D, G, I, K** with **Appendix E** to obtain the supply water temperature.
	- **M** Enter the length of piping installed within the room (i.e., active loop).
- heated to the respective manifold and multiply by 2 to **N** Enter the length of the piping from the room being account for both the supply and return. account for both the supply and return.

**O** Use formula: (**Row M** + **Row N**) = total loop length.

- **P** Use the values in **Rows E** and **M** with **Appendix F** to obtain the flow per loop.
- **Q** Use the values in **Rows H** and **P** with **Appendix G** to obtain the head pressure per loop. Choose the appropriate solution (water or water/glycol solution).
- **R** Enter highest temperature from **Row L**.
- **S** Add and enter all values from **Row P**.
	- **T** Enter highest value from **Row Q**.

![](_page_26_Figure_0.jpeg)

**Figure 8-15: Main-level floor plan (no scale)**

![](_page_27_Picture_356.jpeg)

![](_page_27_Picture_357.jpeg)

![](_page_27_Picture_358.jpeg)

### **Manifold totals**

![](_page_27_Picture_359.jpeg)

 $\blacksquare$ 

Highest pressure head (ft)

**A** Enter the name of the room. The room may have more than one loop.

- **B** Room setpoint temperature is normally 65°F for radiant floor.
- **C** Zone is equal to thermostat.
- **D** Enter the "Floor Unit Load to Room" value from design program printout (upward load).
- **E** Enter the "Floor Unit Load" value from design program printout (total load).
- **F** (**Row D**/2) + **Row B** = floor surface temperature. Do not exceed 87.5°F for all floors (exception: wood floor limit is 80°F).
- **G** Enter the installation method.

**H** Enter the size of PEX piping for project. **I** Refer to **Appendix D** for floor covering information.

- **J** Indicate differential temperature (10°F for residential; 15°F for light commercial; 20°F for commercial).
- **K** Maximum piping o.c. distance is 12" for residential. Do not exceed 9" o.c. under tile or linoleum.
- **L** Use information from **Rows D, G, I, K** with **Appendix E** to obtain the supply water temperature.
- **M** Enter the length of piping installed within the room (i.e., active loop).
- **N** Enter the length of the piping from the room being heated to the respective manifold and multiply by 2 to account for both the supply and return.
- **O** Use formula: (**Row M** + **Row N**) = total loop length.
- **P** Use the values in **Rows E** and **M** with **Appendix F** to obtain the flow per loop.
- **Q** Use the values in **Rows H** and **P** with **Appendix G** to obtain the head pressure per loop. Choose the appropriate solution (water or
- water/glycol solution). **R** Enter highest temperature from **Row L**.
- **S** Add and enter all values from **Row P**.
- **T** Enter highest value from **Row Q**.