

Adaptadores para actuadores térmicos de colectores de acero inoxidable



Project Information

Job name:	Location:
Engineer:	Fecha de envío:
Contractor:	Presentada por:
Manufacturer's representative:	Approved by:

Technical data

Material Plastic

Product information and application use

Spacer Ring VA10 for Thermal Actuator connects Uponor Thermal Actuator, four-wire (A3023522) onto the Uponor Stainless-steel Manifold.



Part name	Part no.	A [Inch]	B [Inch]	C [Inch]	Weight per UOM [lbs/UOM]
Spacer Ring VA10 for Thermal Actuators	A2771060	1.56	0.61	1.56	0.02

Installation

Hand-tighten the spacer ring to the male thread on the manifold and connect the Thermal Actuator, four-wire (A3023522). For more information, refer to the Uponor Stainless-steel Manifold Installation Guide.

Related applications

- Radiant Heating and Cooling Systems
- Permafrost Protection Systems
- Turf Conditioning Systems

Footnotes

-

Contact information

Uponor Inc.
5925 148th Street West
Apple Valley, MN 55124
T 800.321.4739
F 952.891.2008

Uponor Ltd.
6510 Kennedy Road
Mississauga, ON L5T 2X4
T 888.594.7726
F 800.638.9517