

Brass manifold loop end caps

Project information	
Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Technical data

Material Brass

Temp/pressure ratings 73 °F (23 °C) at 160 psi (11 bar) 180 °F (82 °C) at 100 psi (6.9 bar) 200 °F (93 °C) at 80 psi (5.5 bar)

Product information and application use

The Basic End Cap terminates the end of the TruFLOW $^{\text{TM}}$ Jr. Modular Manifolds. Required gaskets and o-rings are included.

The Brass Manifold Loop End Cap closes off unused QS20 loop connections.





Part name	Part no.	A [inch]	B [inch]	C [inch]	D [inch]	End Type 1	E [inch]	Prop 65 label required?	Weight per UOM [lbs/UOM]
Brass Manifold Loop End Cap, R20	A2080020	1.309	1.187	0.453	0.354	ISO 228- G	-	-	0.08
Brass Manifold Loop End Cap Gasket, spare part	A2400020	0.94	0.94	0.09	-	-	-	Yes	0

Part name	Part no.	Codes	Standards	Listings		
Brass manifold loop end caps	All	-	-	-		
In addition, the following parts have additional codes, standards, or listings:						
Brass Manifold Loop End Cap Gasket, spare part	A2400020		ASTM F877			

Installation Related applications

The Basic End Cap threads onto one end of a brass manifold. The seal is aided by a gasket. Do not over-tighten. The Brass Manifold Loop End Cap threads onto a brass manifold outlet. The seal is aided by a gasket. Do not over-tighten. For more information, refer to the Uponor Radiant Installation Handbook. Available accessories: Basic End Cap Gasket, spare part (A2400032); Loop End Gasket, spare part (A2400020)

Radiant Heating and Cooling Systems

Footnotes	Contact information		
	Uponor Inc.	Uponor Ltd.	
	5925 148th Street West	6510 Kennedy Road	
	Apple Valley, MN 55124	Mississauga, ON L5T 2X4	
	T 800.321.4739	T 888.594.7726	
	F 952.891.2008	F 800.638.9517	